



We Are “The Shower Experts”



Easy-To-Apply Liquid Waterproofing

Membrane with Crack Isolation Technology

ShowerSeal is a ready-to-use elastomeric waterproofing membrane which also functions as a sealant, stand-alone crack suppressant and moisture barrier for showers.

Easily applied with a trowel, brush, roller or airless sprayer, ShowerSeal meets ANSI A118.10 for thin-bed, load bearing waterproofing membranes.

How It Works

ShowerSeal forms a continuous, impervious water barrier for waterproofing protection. The product can also be used at floor-to-wall, wall-to-wall, and wall-to-ceiling joints, at drains and protrusions and at all perimeters. The membrane will adhere to the substrate while creating a new surface to accommodate A118.4 or better latex mortars, organic adhesives and epoxy setting materials. ShowerSeal reduces tile failure by protecting tile and other hard surfaces from substrate movement while waterproofing underlying or adjacent building structures.

Fracture-Free, Guaranteed

KBRS, Inc. offers a Limited Lifetime Material Warranty on this product when used with latex modified mortar in accordance with ANSI A118.4. Please contact Customer Service for details at (912) 352-0442.

ShowerSeal Features and Benefits

- Suitable for interior and exterior use
- Changes from light green to deep-sea green when cured
- Protects against reflective cracking and delamination
- Tile can be installed the same day as membrane
- Can be easily applied with trowel, roller, brush or sprayer
- Serves as a waterproof/vapor barrier
- Ideal for Spa Applications
- Assures waterproof integrity of corners and seams
- Eases application in hard to reach areas

Recommended for Installation Under:

Installation of ceramic, porcelain, stone, marble and granite tile.

Suitable Substrates:

- Concrete:** Poured, pre-stressed and pre-cast concrete. Concrete backerboard, mud beds, gypsum, lightweight concrete and patching/leveling compounds. **Wood:** Exterior or exposure 1 plywood, APA-rated sheathing, Sturd-I-Floor, hardwood, tongue and groove and OSB with standard face. (Gap between sheeting as required.) **Other Substrates:** Ceramic and porcelain tile, stone, terrazzo, VCT/VAT, metal, radiant-heated, painted and sealed floors and floors damaged by dry shrinkage and structural movement.
- Product coverage is contingent upon type of applicator used and porosity of substrate. For highly absorptive surfaces, additional coats may be required.
 - Substrates must be dry, well adhered, and clean of all bond breakers including wax, petroleum sealers, dirt, grease, oil or other inhibitors.
 - Refer to waterproofing applications in the current TCA handbook for additional installation guidelines.

**See Installation
Instructions**



25-F Telfair Place
Savannah, GA 31415
Phone: (912) 352-0442 FAX: (912) 352-4204



Installation Instructions:

- 1.** Installation begins with a clean, dry substrate. Substrates must be well adhered and free of wax, petroleum sealers, dirt, grease, oil or other bond breakers. Substrate temperature should be at least 65°F.
- 2.** Fill all seams and gaps with latex modified thin-set. Tape seams and gaps larger than 1/8".
- 3.** Apply ShowerSeal with a rough textured synthetic roller (3/4"), or paint brush. (**Note:** Use a roller for large areas, and a paint brush for seams and corners)
- 4.** A 3-4 coats of SubSeal applied in the opposite direction is recommended for water containment and/or if voids or pinholes are found. The combined dry coating thickness should be a minimum of 47 mil and should not exceed 115 mil when wet.
- 5.** This product is formulated to change from light green to deep-sea green when fully cured. Average dry time is about two hours but may vary due to temperature, humidity, internal moisture level, porosity of substrate and application thickness.

Coverage Estimates:

For waterproofing the seams where the backerboard meets the shower base, **1 US Quart** should be sufficient.

For waterproofing an entire shower (shower base & walls) we recommend **1 US Gallon**, or more depending on the size of the shower.



25-F Telfair Place
Savannah, GA 31415
Phone: (912) 352-0442 FAX: (912) 352-4204